



AUTO GATE LATCH

1. Place catch on post horizontally where required. Mark out holes for catch on post.
2. Remove catch and drill pilot holes for screws into post. Replace catch and fix to post using screws provided.
3. Align strike bar horizontal to catch. Mark out holes for strike bar on gate.
4. Remove strike bar and drill pilot holes for screws into gate. Replace strike bar and fix to gate using screws provided.