



MONKEY TAIL BOLT

1. Place bolt assembly at top of door and vertically where required. Mark out holes for bolt assembly on door.
2. Remove bolt assembly and drill pilot holes for screws into door. Replace bolt assembly and fix to door using screws provided.
3. With door closed, set bolt to engaged position. Mark out where bolt makes contact with top frame.
4. Clear marked area and drill a hole wide enough and deep enough to receive bolt.
5. Place square receiver plate on top frame central to drilled hole. Mark out screw holes on top frame.
6. Remove square receiver plate and drill pilot holes for screws into top frame. Replace square receiver plate and fix to top frame using screws provided.