



## **PADLOCK BOLTS**

---

1. Place bolt assembly on gate horizontally where required. Mark out holes for bolt assembly on gate.
2. Remove bolt assembly and drill pilot holes for screws into gate. Replace bolt assembly and fix to gate using screws provided.
3. Set bolt to engaged position. Align staple horizontal to bolt. Mark out holes for staple on frame.
4. Remove staple and drill pilot holes for screws into frame. Replace staple and fix to frame using screws provided.