



SPRING LOADED BOLTS

1. Place bolt assembly on trailer where required. Mark out holes for bolt assembly position on trailer.
2. Remove bolt assembly and drill pilot holes for screws and bolts into trailer. Replace bolt assembly and fix to trailer using screws and bolts provided.
3. With bolt pulled back, mark out where bolt makes contact with trailer ramp/gate. Drill a hole into trailer ramp/gate to receive bolt when closed.