



## HASP & STAPLE

---

1. Place hasp on gate horizontally where required. Mark out holes for hasp on gate.
2. Remove hasp and drill pilot holes for screws into gate. Replace hasp and fix to gate using screws provided.
3. Align staple horizontal to hasp. Mark out holes for staple on wall.
4. Remove staple and drill pilot holes for screws into wall. Replace staple and fix to wall using screws provided.